

GMC 600 PRO

Handheld Radiation Alert Detector


US Made  USA
Highly-Sensitive Pancake
Geiger-Müller Tube

a β γ x

The GMC 600+ was designed to meet the requirements of emergency response personnel. It has the same valuable features, small size, and quality of the Inspector. However, instead of the built-in detector, it has the added versatility of an external probe. The carrying case has a clear window panel providing full view of the readout, count light, access to the switches, and a convenient belt loop for carrying the instrument. A small pocket is provided for a check source. The protective probe cover on the uniquely designed carrying case folds easily out of the way to allow one-handed operation if desired.

Specifications:

Range of dose rate indications, $\mu\text{Sv/h}$	0.001 to ~4250
Range of exposure dose rate indications, mRem/h	0.001 to ~425
Reproducibility of indication	10%
Range of CPM	>1,000,000 (continuously)
Total CPM	999999999
Alarm levels by CPM	> 0 (continuously)
Alarm levels by $\mu\text{Sv/h}$	0.001 to 4250
Alarm levels by mRm/h	0.001 to 425
Date indication	YYYY-MM-DD (continuously)
Time indication	HH-MM-SS (continuously)
Elapsed time indication	99 years(maximum)
Timed Count	1 Second to 256 days(programmable)
Scheduled Timed Count	0 Second to 256 days(programmable)
Sensor installed:	Pancake SBT-11 (GMC-600) Pancake LND-7317 (GMC-600+)
Radiation detection	$\alpha, \beta, \gamma, \text{x-Ray}$
Detectable Radiation level(GMC-600 Plus)	$\alpha(2.5 \text{ MeV}), \beta(50 \text{ KeV}), \gamma, \text{x-Ray}(10 \text{ keV})$
GAMMA SENSITIVITY CO60 (CPS/mR/HR)	58
Detectable Radiation level (GMC-600)	$\alpha(3 \text{ MeV}), \beta(100 \text{ KeV}), \gamma, \text{x-Ray}(10 \text{ keV})$
Instrument Background	≤ 2 pulses/s
Working Voltage	3.6-3.7V
Display	LCD dot matrix, back lighted
On board Memory	1M Bytes flash memory for data storage
Power: Consumption	25mW – 125mW (count rate dependant)
Power: Supply	3.7V Li-Ion battery / USB power
Dimensions	135 x 78 x 42 mm(5.25"x 3" x 1.65")



GMC 600 PRO

